



Dimension Guide


Bottom freezer refrigerator

Model:



EBM3402L-B



When positioned in a corner area, spacing a minimum of 350mm on the hinge side will allow the doors to open enough to enable the removal of bins and shelves.



Allow a minimum of 30mm clearance on both sides of the refrigerator and 50mm clearance at the back.



Allow a minimum of 10mm clearance above the hinge cover. If you do not have a cupboard with allowance for air flow above the refrigerator, the recommended clearance area on top increases to 90mm.

Bottom freezer refrigerator	Door width (W)	Total depth (D)	Maximum height (H)	Cabinet width (W1)	Cabinet height (H1)	Cabinet depth (D1)	Depth door open (D2)
EBM3402L-B	598	650	1756	595	1740	586	1199

Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions.

© 2025 Electrolux S.E.A PTE. LTD. ELX_DIM_EBM3402L-B_Dec25